

iii. **DMX Protocols (Full Function with 7 Channels)**

Channel	Function	Value
Channel 1	Red	0-255
Channel 2	Green	0-255
Channel 3	Blue	0-255
Channel 4	Dimmer/ Strobe	0-255
Channel 5	Chase 1	0-15
	Chase 2	16-31
	Chase 3	32-47
	Chase 4	48-63
	Chase 5	64-79
	Chase 6	80-95
	Chase 7	96-111
	Chase 8	112-127
	Chase 9	128-143
	Chase 10	144-159
	Chase 11	160-175
	Chase 12	176-191
	Chase 13	192-207
	Chase 14	208-223
	Chase 15	224-239
	Chase 16	240-255
Channel 6	Speed	0-255
Channel 7	Fade Time	0-255

iv. **Setting the DMX Control Channel**

There are total of 40 LED cells on Tracpod 84 light fixture. The LED cells can be set to control as 1, 2, 5, 10, or 40 cells. Total of 6 DMX control channel modes are available.

