



## SPECIFICATIONS:

Model: Supply Voltage: Weight: Size: Fuse: Power Consumption: Working Position: Duty Cycle: Warranty: EZ8 System 120V 50Hz 5 lbs./2.3kgs 11.75"L x 8.75"W x 6"H 1 Amp 30W Any Safe position None 1 Year

**CAUTION!** Please read and understand these instructions before installing or operating this unit.


**Caution!** Never open unit when in use. Always disconnect main power before replacing the fuse. Remember to always replace with the exact same type of fuse.

### **Operating Instructions:**

The EZ8 System is an on/off power control center designed to eliminate messy cables. The EZ8 System features 8 on and off switches, 15 amps, and a 25 ft. cable. It's ideal for switching lighting and audio equipment on and off.

**1** Year Limited Warranty: Eliminator Lighting warranty is valid from the date of purchase. Our 1 year limited warranty covers manufacturing defects only. Serial number, place of purchase with dated valid receipt must be submitted at time of service. Eliminator Lighting warranty does not cover items or parts prone to wear and tear: lamps, fuses, brushes and belts. Eliminator Lighting warranty is only valid with-in the United States.

#### Important Notice: Never attempt to run more than 2 power packs per a controller -More than 2 power packs can cause damage to the controller and power packs!



## **CONTROLS AND COMPONENTS:**

- 1. MASTER ON/OFF SWITCH.
- 2. INDIVIDUAL CHANNEL SWITCHES.
- 3. FLASH ON BUTTON FOR EACH INDIVIDUAL CHANNEL.
- 4. 9 PIN LINE OUT CONNECTOR.
- 5. 12V POWER SUPPLY
- 6. FUSE
- 7. CHANNEL 1-8 110V SWITCHED SOCKETS.
- 8. UNSWITCHED 110V SOCKET FOR CONSTANT ON ITEM OR LINKING AC TO ANOTHER RELAY PACK.
- 9. 9 PIN LINE OUTPUT FOR LINKING PACKS.
- 10. 9 PIN LINE INPUT FROM SC-8FC OR FROM ANOTHER SC- RP8.
- 11. 15 AMP CIRCUIT BREAKER.
- 12. A/C CORD AND PLUG.

# SAMPLE SET UP

