

## *X-Treme/C*™ *X-Treme*™*Controller*

**Thank you for purchasing this American DJ® product. Please read the following instructions before installing or using your new unit.**

### **Operating Instructions:**

The *X-Treme/C*™ is a sound -activated controller for the *X-Treme*™ light projectors. It uses DMX512 protocol. When you provide power to the unit it is in blackout mode press blackout button LED will turn off and any *X-Treme*™ connected will begin to operate. the *X-Treme/C*™ will control 4 *X-Treme*™ projectors.

**Program 1** has slow movement.

**Program 2** has a fast movement

**Program 3** has fast movement with a larger arc.

**Program 4** combines the first 3 programs.

Please make sure to read *X-Treme*™ owners manual for proper setup of projectors.

For service, contact your *American DJ*® dealer.

### **Model: *X-Treme/C*™**

#### **SPECIFICATIONS:**

Weight:	2 lbs.11oz
Size:	11.25" x 5.25" x 2.75"
Voltage:	120V AC 60Hz
Fuse:	1A
Output:	DMX512