

LED Moon Beam



CAUTION! Please read and understand these instructions before installing or operating this unit.

Operating Instructions:

Model: Supply Voltage: LEDs: Power Consumption: Weight: Size: Fuse: Working Position: Duty Cycle: DMX Channels: Colors: Warranty:

SPECIFICATIONS:

LED Moon Beam 100V ~ 240V 60Hz/50Hz 5 x 3W LEDs 30W 5lbs./ 2.2kgs. 7.7" (L) x 8" (W) x 10.5" (H) 1 Amp Any Safe position None 3 RGBWA 1 Year

Caution! Never open unit when in use. Always disconnect main power before servcing. Remember to always replace with the exact same type fuse.

This unit is a 3 channel DMX intelligent LED unit. It can be run as a stand-alone or in a master-slave configuration. The unit has 3 operating modes; sound active mode, auto mode or DMX controlled. This unit has been tested at the factory, there is no assembly required. The unit is ready to be plugged in to a power outlet. To run the different operating modes, see the next page. To enhance the beams use this effect with a fog machine.

Fuse Replacement: Locate and remove the unit's power cord. Once the cord has been removed located the fuse holder located inside the power socket. Insert a flat-head screw driver into the power socket and gently pry out the fuse holder. Remove the bad fuse and replace with a new one. The fuse holder has a built-in socket for a spare fuse be sure not to confuse the spare fuse with active fuse.

Auto Run Mode:

- 1. Plug the fixture in and press the MODE button until "AU.XX" is displayed. "XX" represents the current set running speed.
- 2. Press ENTER and use the UP and DOWN buttons to adjust the running speed. The running speed can be adjusted between "AU.00" (slowest speed) to "AU.99" (fastest speed).

Sound Active Mode:

In this mode the LED Moon Beam will react to sound.

- 1. Plug the fixture in and press the MODE button until "SU.XX" is displayed. "XX" represents the sound sensitvity level.
- 2. Press ENTER and use the UP and DOWN buttons to adjust the sound sensitivity, the sensitivity can be adjusted between "SU.01" (least sensitive) to "SU.99" (most sensitive).

DMX Mode:

Operating through a DMX controller gives the user the freedom to create their own programs tailored to their own individual needs. The LED Mushroom has 3 DMX channels. See the chart on the next page for the DMX traits and values.

- 1. This function will allow you to control each individual fixture's traits with a standard DMX 512 controller.
- 2. To run your fixture in DMX mode press the MODE button until "AXXX" is displayed. "XXX" represents the current displayed DMX address. Press ENTER and use the UP or DOWN buttons to find your desired DMX address.
- 3. After you have chosen your desired DMX address plug in the fixture via the XLR connections to any standard DMX controller.

Master-Slave Configuration:

- 1. Daisy chain your units via the XLR connector on the rear of the unit. Use standard XLR data cables to link your units together. Remember that the Male XLR connector is the input and the Female XLR connector is the ouput. The first unit in the chain (master) will use the female XLR connector only. The last unit in the chain will use the male XLR connector only.
- 2. Connect the first "Slave" unit to the "Master."
- 3. Set the "Master" unit to your desired mode of operation. On the "Slave" unit, set the DMX address to "001". The "Slave" unit will now follow the "Master".

DMX TRAITS: 3 CHANNELS		
CHANNEL 1: COLOR MACROS		CHANNEL 1: COLOR MACROS
0 - 4 =	BLACKOUT	105 - 109 = RED, GREEN, & WHITE
5 - 9 =	RED	110 - 114 = RED, GREEN, & AMBER
10 - 14 =	GREEN	115 - 119 = RED, BLUE, & AMBER
15 - 19 =	BLUE	120 - 124 = RED, BLUE, & WHITE
20 - 24 =	WHITE	125 - 129 = GREEN, AMBER, & BLUE
25 - 29 =	AMBER	130 - 134 = RED, GREEN, BLUE, & WHITE
30 - 34 =	RED & GREEN	135 - 139 = GREEN, BLUE, WHITE, & AMBER
35 - 39 =	GREEN & BLUE	140 - 144 = RED, GREEN, BLUE, & AMBER
-	BLUE & WHITE	145 - 149 = RED, GREEN, WHITE, & AMBER
	WHITE & AMBER	150 - 154 = R/G/B/W/A
	RED & AMBER	155 - 200 = COLOR CHANGE SLOW - FAST
	GREEN & AMBER	201 - 250 = COLOR FADE SLOW - FAST
	BLUE & AMBER	251 - 255 = SOUND ACTIVE
65 - 69 =	RED & BLUE	CHANNEL 2: STROBING/SOUND SENSITIVITY
70 - 74 =	RED & WHITE	0 - 255 = STROBING SLOW - FAST
75 - 79 =	GREEN & WHITE	0 - 255 = SOUND SENITIVITY ADJUSTMENT
80 - 84 =	RED, GREEN, & BLUE	LEAST SENSITIVE - MOST SENSITIVE
85 - 89 =	GREEN, BLUE, & WHITE	
90 - 94 =	BLUE, WHITE, & AMBER	CHANNEL 3: LED ROTATION
95 - 99 =	RED, WHITE, & AMBER	0 - 255 = ROTATING SLOW - FAST
100 - 104 =	GREEN, WHITE, & AMBER	

1 Year Limited Warranty: Eliminator Lighting warranty is valid from the date of purchase. Our 1 year limited warranty covers manufacturing defects only. Serial number, place of purchase with dated valid receipt must be submitted at time of service. Eliminator Lighting warranty does not cover items or parts prone to wear and tear: lamps, LEDs, fuses, brushes and belts. Eliminator Lighting warranty is only valid with-in the United States.

©Eliminator® Los Angeles, CA. - www.EliminatorLighting.com